**PL-FM-3010-0203**
February 2003
Issue 1

# Model LG Series Parts Listing



# Model LG Series Parts Listing With Decimal Dial (LBF)

| US List Price | Ref. No. | Part No. | Description | LG 002 | LG 005 | LG 010 | LG 020 | LG 030 | LG 050 | LG 075 | LG 100 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 1 | NC002669 | Plate, Upper Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | NC002670 | Plate, Lower Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 3 | NC002662 | Frame Support, Upper | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 4 | NC002661 | Frame Support, Lower | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 5 | 2630 | Ball Bushing | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 6 | 13007 | Retaining Ring | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 7 | 8178 | Screw, #6-32 x 1/4 FH | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| | 8 | E08-245 | Screw, #4-40 x 3/8 FH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 9 | 12125 | Shaft, Main | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 10 | NC002676 | Support, Spring - Center | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 11 | NC002663 | Support, Spring - Medium | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 12 | NC002664 | Support, Spring - Small | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 13 | 3168 | Nut, #6 Hex | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 14 | 10390 | Washer, #6 Lock | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 15 | NC002715 | Bearing Support Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 16 | NC002716 | Bezel, Dial Indicator | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 17 | N/A | | | | | | | | | |
| | 18 | NC002675 | Spring Support, Calibrator | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 19 | N/A | | | | | | | | | |
| | 20 | N/A | | | | | | | | | |
| | 21 | 12122 | Taper, Pin #6/0 x 1/2 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 22 | 900-04-046 | Screw, #5-40 x 3/4 SHC | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 23 | E02-236 | Washer, #5 Flat | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 24 | NC002158 | Screw, Set #4-40 x 3/16 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 25 | NC002677-01 | Dial Indicator Assembly | 1 | - | - | - | - | - | - | - |
| | | NC002677-02 | Dial Indicator Assembly | - | 1 | - | - | - | - | - | - |
| | | NC002677-03 | Dial Indicator Assembly | - | - | 1 | - | - | - | - | - |
| | | NC002677-04 | Dial Indicator Assembly | - | - | - | 1 | - | - | - | - |
| | | NC002677-05 | Dial Indicator Assembly | - | - | - | - | 1 | - | - | - |
| | | NC002677-06 | Dial Indicator Assembly | - | - | - | - | - | 1 | - | - |
| | | NC002677-07 | Dial Indicator Assembly | - | - | - | - | - | - | 1 | - |
| | | NC002677-08 | Dial Indicator Assembly | - | - | - | - | - | - | - | 1 |
| | 26 | NC002674 | Spring, Compression | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 27 | NC002672 | Bracket, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 28 | NC002673 | Plate, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 29 | E08-241 | Screw, #4-40 x 3/16 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 30 | E08-138 | Screw, #4-40 x 1/4 RH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 31 | NC002671 | Gauge Mounting Plate | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 32 | E08-159 | Screw, #4-40 x 1/4 FH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 33 | NC002713 | Housing, Top Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 34 | NC002714 | Housing, Bottom Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

**PL-FM-3010-0203**
February 2003
Issue 1

## Model LG Series Parts Listing
## With Decimal Dial (LBF)

| US List Price | Ref. No. | Part No. | Description | LG 002 | LG 005 | LG 010 | LG 020 | LG 030 | LG 050 | LG 075 | LG 100 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 35 | E08-242 | Screw, M3-0.5 x 10M PH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 36 | E08-243 | Screw, #4-40 x 3/4 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 37 | E08-244 | Screw, #4-40 x 1/2 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 38 | NC002679-01 | Spring, Main | 2 | - | - | - | - | - | - | - |
| | | NC002679-02 | Spring, Main | - | 2 | - | - | - | - | - | - |
| | | NC002679-03 | Spring, Main | - | - | 2 | - | - | - | - | - |
| | | NC002679-04 | Spring, Main | - | - | - | 2 | - | - | - | - |
| | | NC002679-05 | Spring, Main | - | - | - | - | 2 | - | - | - |
| | | NC002679-06 | Spring, Main | - | - | - | - | - | 2 | - | - |
| | | NC002679-07 | Spring, Main | - | - | - | - | - | - | 2 | - |
| | | NC002679-08 | Spring, Main | - | - | - | - | - | - | - | 2 |
| | 39 | SPK-LG-002 | Spring, Trim | 2 | - | - | - | - | - | - | - |
| | | SPK-LG-005 | Spring, Trim | - | 2 | - | - | - | - | - | - |
| | | SPK-LG-010 | Spring, Trim | - | - | 2 | - | - | - | - | - |
| | | SPK-LG-020 | Spring, Trim | - | - | - | 2 | - | - | - | - |
| | | SPK-LG-030 | Spring, Trim | - | - | - | - | 2 | - | - | - |
| | | SPK-LG-050 | Spring, Trim | - | - | - | - | - | 2 | - | - |
| | | SPK-LG-075 | Spring, Trim | - | - | - | - | - | - | 2 | - |
| | | SPK-LG-100 | Spring, Trim | - | - | - | - | - | - | - | 2 |
| | 40 | NC002710 | Carrying Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 41 | NC002711 | Operator's Manual | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 47 | SPK-FMG-011A | Adapter, Flat | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 48 | SPK-FMG-010A | Adapter, Notch | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 49 | SPK-FMG-009A | Adapter, Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 50 | SPK-FMG-008A | Adapter, Chisel Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 51 | SPK-FMG-012A | Hook, Stationary | 1 | 1 | 1 | 1 | 1 | - | - | - |
| | | SPK-FMG-012B | Hook, Stationary | - | - | - | - | - | 1 | 1 | 1 |
| | 53 | NC002678 | Latch, Pawl Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 54 | E02-235 | Washer, #4 Split Lock | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 55 | SPK-FMG-013A | Extension Rod | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

All information is subject to change without notice.



# Model LG Series Parts Listing
# With Metric Dial (KGF)

| US List Price | Ref. No. | Part No. | Description | LG 1KG | LG 2KG | LG 3KG | LG 5KG | LG 10KG | LG 20KG | LG 30KG | LG 50KG |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 1 | NC002669 | Plate, Upper Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | NC002670 | Plate, Lower Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 3 | NC002662 | Frame Support, Upper | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 4 | NC002661 | Frame Support, Lower | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 5 | 2630 | Ball Bushing | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 6 | 13007 | Retaining Ring | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 7 | 8178 | Screw, #6-32 x 1/4 FH | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| | 8 | E08-245 | Screw, #4-40 x 3/8 FH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 9 | 12125 | Shaft, Main | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 10 | NC002676 | Support, Spring - Center | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 11 | NC002663 | Support, Spring - Medium | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 12 | NC002664 | Support, Spring - Small | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 13 | 3168 | Nut, #6 Hex | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 14 | 10390 | Washer, #6 Lock | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 15 | NC002715 | Bearing Support Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 16 | NC002716 | Bezel, Dial Indicator | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 17 | N/A | | | | | | | | | |
| | 18 | NC002675 | Spring Support, Calibrator | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 19 | N/A | | | | | | | | | |
| | 20 | N/A | | | | | | | | | |
| | 21 | 12122 | Taper, Pin #6/0 x 1/2 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 22 | 900-04-046 | Screw, #5-40 x 3/4 SHC | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 23 | E02-236 | Washer, #5 Flat | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 24 | NC002158 | Screw, Set #4-40 x 3/16 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 25 | NC002677-13 | Dial Indicator Assembly | 1 | - | - | - | - | - | - | - |
| | | NC002677-14 | Dial Indicator Assembly | - | 1 | - | - | - | - | - | - |
| | | NC002677-15 | Dial Indicator Assembly | - | - | 1 | - | - | - | - | - |
| | | NC002677-16 | Dial Indicator Assembly | - | - | - | 1 | - | - | - | - |
| | | NC002677-17 | Dial Indicator Assembly | - | - | - | - | 1 | - | - | - |
| | | NC002677-18 | Dial Indicator Assembly | - | - | - | - | - | 1 | - | - |
| | | NC002677-19 | Dial Indicator Assembly | - | - | - | - | - | - | 1 | - |
| | | NC002677-20 | Dial Indicator Assembly | - | - | - | - | - | - | - | 1 |
| | 26 | NC002674 | Spring, Compression | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 27 | NC002672 | Bracket, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 28 | NC002673 | Plate, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 29 | E08-241 | Screw, #4-40 x 3/16 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 30 | E08-138 | Screw, #4-40 x 1/4 RH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 31 | NC002671 | Gauge Mounting Plate | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 32 | E08-159 | Screw, #4-40 x 1/4 FH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 33 | NC002713 | Housing, Top Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 34 | NC002714 | Housing, Bottom Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

**PL-FM-3010-0203**
February 2003
Issue 1

## Model LG Series Parts Listing
## With Metric Dial (KGF)

| US List Price | Ref. No. | Part No. | Description | LG 1KG | LG 2KG | LG 3KG | LG 5KG | LG 10KG | LG 20KG | LG 30KG | LG 50KG |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 35 | E08-242 | Screw, M3-0.5 x 10M PH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 36 | E08-243 | Screw, #4-40 x 3/4 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 37 | E08-244 | Screw, #4-40 x 1/2 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 38 | NC002679-09 | Spring, Main | 2 | - | - | - | - | - | - | - |
| | | NC002679-10 | Spring, Main | - | 2 | - | - | - | - | - | - |
| | | NC002679-11 | Spring, Main | - | - | 2 | - | - | - | - | - |
| | | NC002679-12 | Spring, Main | - | - | - | 2 | - | - | - | - |
| | | NC002679-13 | Spring, Main | - | - | - | - | 2 | - | - | - |
| | | NC002679-14 | Spring, Main | - | - | - | - | - | 2 | - | - |
| | | NC002679-15 | Spring, Main | - | - | - | - | - | - | 2 | - |
| | | NC002679-16 | Spring, Main | - | - | - | - | - | - | - | 2 |
| | 39 | SPK-LG-1KG | Spring, Trim | 2 | - | - | - | - | - | - | - |
| | | SPK-LG-2KG | Spring, Trim | - | 2 | - | - | - | - | - | - |
| | | SPK-LG-3KG | Spring, Trim | - | - | 2 | - | - | - | - | - |
| | | SPK-LG-5KG | Spring, Trim | - | - | - | 2 | - | - | - | - |
| | | SPK-LG-10KG | Spring, Trim | - | - | - | - | 2 | - | - | - |
| | | SPK-LG-20KG | Spring, Trim | - | - | - | - | - | 2 | - | - |
| | | SPK-LG-30KG | Spring, Trim | - | - | - | - | - | - | 2 | - |
| | | SPK-LG-50KG | Spring, Trim | - | - | - | - | - | - | - | 2 |
| | 40 | NC002710 | Carrying Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 41 | NC002711 | Operator's Manual | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 47 | SPK-FMG-011A | Adapter, Flat | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 48 | SPK-FMG-010A | Adapter, Notch | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 49 | SPK-FMG-009A | Adapter, Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 50 | SPK-FMG-008A | Adapter, Chisel Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 51 | SPK-FMG-012A | Hook, Stationary | 1 | 1 | 1 | 1 | 1 | - | - | - |
| | | SPK-FMG-012B | Hook, Stationary | - | - | - | - | - | 1 | 1 | 1 |
| | 53 | NC002678 | Latch, Pawl Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 54 | E02-235 | Washer, #4 Split Lock | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 55 | SPK-FMG-013A | Extension Rod | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

# Model LG Series Parts Listing
# With S.I. Dial (Newtons)

| US List Price | Ref. No. | Part No. | Description | LG 10N | LG 20N | LG 30N | LG 50N | LG 100N | LG 200N | LG 300N | LG 500N |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 1 | NC002669 | Plate, Upper Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | NC002670 | Plate, Lower Support | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 3 | NC002662 | Frame Support, Upper | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 4 | NC002661 | Frame Support, Lower | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 5 | 2630 | Ball Bushing | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 6 | 13007 | Retaining Ring | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 7 | 8178 | Screw, #6-32 x 1/4 FH | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| | 8 | E08-245 | Screw, #4-40 x 3/8 FH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 9 | 12125 | Shaft, Main | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 10 | NC002676 | Support, Spring - Center | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 11 | NC002663 | Support, Spring - Medium | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 12 | NC002664 | Support, Spring - Small | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 13 | 3168 | Nut, #6 Hex | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 14 | 10390 | Washer, #6 Lock | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 15 | NC002715 | Bearing Support Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 16 | NC002716 | Bezel, Dial Indicator | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 17 | N/A | | | | | | | | | |
| | 18 | NC002675 | Spring Support, Calibrator | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 19 | N/A | | | | | | | | | |
| | 20 | N/A | | | | | | | | | |
| | 21 | 12122 | Taper, Pin #6/0 x 1/2 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 22 | 900-04-046 | Screw, #5-40 x 3/4 SHC | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 23 | E02-236 | Washer, #5 Flat | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 24 | NC002158 | Screw, Set #4-40 x 3/16 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| | 25 | NC002677-24 | Dial Indicator Assembly | 1 | - | - | - | - | - | - | - |
| | | NC002677-25 | Dial Indicator Assembly | - | 1 | - | - | - | - | - | - |
| | | NC002677-26 | Dial Indicator Assembly | - | - | 1 | - | - | - | - | - |
| | | NC002677-27 | Dial Indicator Assembly | - | - | - | 1 | - | - | - | - |
| | | NC002677-28 | Dial Indicator Assembly | - | - | - | - | 1 | - | - | - |
| | | NC002677-29 | Dial Indicator Assembly | - | - | - | - | - | 1 | - | - |
| | | NC002677-30 | Dial Indicator Assembly | - | - | - | - | - | - | 1 | - |
| | | NC002677-31 | Dial Indicator Assembly | - | - | - | - | - | - | - | 1 |
| | 26 | NC002674 | Spring, Compression | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 27 | NC002672 | Bracket, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 28 | NC002673 | Plate, Max Capture | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 29 | E08-241 | Screw, #4-40 x 3/16 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 30 | E08-138 | Screw, #4-40 x 1/4 RH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 31 | NC002671 | Gauge Mounting Plate | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 32 | E08-159 | Screw, #4-40 x 1/4 FH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 33 | NC002713 | Housing, Top Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 34 | NC002714 | Housing, Bottom Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

**PL-FM-3010-0203**
February 2003
Issue 1

## Model LG Series Parts Listing
## With S.I. Dial (Newtons)

| US List Price | Ref. No. | Part No. | Description | LG 10N | LG 20N | LG 30N | LG 50N | LG 100N | LG 200N | LG 300N | LG 500N |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 35 | E08-242 | Screw, M3-0.5 x 10M PH | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 36 | E08-243 | Screw, #4-40 x 3/4 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 37 | E08-244 | Screw, #4-40 x 1/2 PH | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 38 | NC002679-09 | Spring, Main | 2 | - | - | - | - | - | - | - |
| | | NC002679-10 | Spring, Main | - | 2 | - | - | - | - | - | - |
| | | NC002679-11 | Spring, Main | - | - | 2 | - | - | - | - | - |
| | | NC002679-12 | Spring, Main | - | - | - | 2 | - | - | - | - |
| | | NC002679-13 | Spring, Main | - | - | - | - | 2 | - | - | - |
| | | NC002679-14 | Spring, Main | - | - | - | - | - | 2 | - | - |
| | | NC002679-15 | Spring, Main | - | - | - | - | - | - | 2 | - |
| | | NC002679-16 | Spring, Main | - | - | - | - | - | - | - | 2 |
| | 39 | SPK-LG-10N | Spring, Trim | 2 | - | - | - | - | - | - | - |
| | | SPK-LG-20N | Spring, Trim | - | 2 | - | - | - | - | - | - |
| | | SPK-LG-30N | Spring, Trim | - | - | 2 | - | - | - | - | - |
| | | SPK-LG-50N | Spring, Trim | - | - | - | 2 | - | - | - | - |
| | | SPK-LG-100N | Spring, Trim | - | - | - | - | 2 | - | - | - |
| | | SPK-LG-200N | Spring, Trim | - | - | - | - | - | 2 | - | - |
| | | SPK-LG-300N | Spring, Trim | - | - | - | - | - | - | 2 | - |
| | | SPK-LG-500N | Spring, Trim | - | - | - | - | - | - | - | 2 |
| | 40 | NC002710 | Carrying Case | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 41 | NC002711 | Operator's Manual | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 47 | SPK-FMG-011A | Adapter, Flat | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 48 | SPK-FMG-010A | Adapter, Notch | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 49 | SPK-FMG-009A | Adapter, Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 50 | SPK-FMG-008A | Adapter, Chisel Point | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 51 | SPK-FMG-012A | Hook, Stationary | 1 | 1 | 1 | 1 | 1 | - | - | - |
| | | SPK-FMG-012B | Hook, Stationary | - | - | - | - | - | 1 | 1 | 1 |
| | 53 | NC002678 | Latch, Pawl Assembly | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 54 | E02-235 | Washer, #4 Split Lock | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 55 | SPK-FMG-013A | Extension Rod | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |